



GR	MGS			LAT
	R	Y	G	
1	1.1	1.2	1.3	021 022
2	1.4	1.5	1.6	051 052
3	1.7	1.8	1.9	081 082
4	2.1	2.2	2.3	121 122
5	2.4	2.5	2.6	311 312
6	2.7	2.8	2.9	321 322
7	3.1	3.2	3.3	341 342
8	3.4	3.5	3.6	351 352
9	3.7			641
9			3.9	621

przycisk	wejście	wyjście
3101 3102	1 - 2	33 - 34
3201 3202	3 - 4	33 - 34
3401 3402	5 - 6	35 - 36
3501 3502	7 - 8	35 - 36

